

DESIG	of P	DRAWN BY	DART AEROSPACE HAWKESBURY, ONTARIO, CANA	
CHECK	KED VI	APPROVED	DRAWING NO.	REV. A
	#		DSI 9376	SHEET 1 OF 1
DATE			TITLE	SCALE
07.04.24			CROSSTUBE CLAMP CHANGE	NTS
Α		07.04.24	NEW ISSUE	

## DART SERVICE INSTRUCTION

TO AMEND INSTALLATION INSTRUCTIONS IIN-D212-664 REV. D
AND INSTRUCTIONS FOR CONTINUED AIRWORTHINESS ICA-D212-664 Rev.3

REF. CANADIAN STC: SH01-9 ISSUE 3 REF. FAA STC: SR01298NY

The MS21920-XX clamps used to secure the supports and chafing shields for the D212-664-101/-201 and D412-664-105/-203/-205 Crosstube Installations may be difficult to install because of tolerance stack-up.

It is acceptable to use smaller or larger sized MS21920-XX clamps then those mentioned in IIN-D212-664 Rev.D and ICA-D212-664 Rev.3. Ensure that after torquing the clamps per ICA-D212-664, that at least 1.5 threads are showing in safety and that the nut has not bottomed-out.

For the crosstube installations, the following clamps are recommended:

QTY -101	QTY -105	QTY -201	QTY -203	QTY -205	P/N	DESCRIPTION
Х					D212-664-101	Crosstube Installation, 204/205/210/212/214/412 High Fwd
	Х				D412-664-105	Crosstube Installation, 412 Low-Narrow Fwd
		Х			D212-664-201	Crosstube Installation, 204/205/210/212/214 High Aft
			Х		D412-664-203	Crosstube Installation, 412 High Aft
				Χ	D412-664-205	Crosstube Installation, 412 Low-Narrow Aft
	2				MS21920-24	Clamp (for attaching D3189-3 Chafing Shield)
4	4				MS21920-25	Clamp (for attaching D2893-1 Support)
		4	4	4	MS21920-28	Clamp (for attaching D2940-1 Support / D3189-1 Chafing Shield)
			2	2	MS21920-30	Clamp (for attaching D2896-1 Support)

CANADA
DEPARTMENT OF TRANSPORT
AIRCRAFT CERTIFICATION
BRANCH
DAO # 01-0-01

ARPROVE

D. SHEPHERD (DE # 02

DATE: 07.04.24
CERT. NO.: SH01-9
ISSUE NO.: 3